

Advanced Lighting Technology

Underwater Video Light VIDEO 8X 18000Im CRI85

Operating Instructions



For Professionals Who Know The Difference.

BEFORE STARTING

- Read operating instructions.
- Keep O-ring clean and grease regularly.
- For storage charge the battery to 30-60%. Storing a fully charged or empty battery is detrimental to the battery's life in the long run.
- Discharge/charge battery at least every 6 months.
- Remove the battery from casing when storing the light.
- Charge the battery before every dive.

TABLE OF CONTENTS

Instructions	3
Magnetic Switch	3
Battery Charging	3
Battery Maintenance	3
Battery Protection Circuit	3
Charge Level Indicator	3
Use in Air	3
How to Open the Casing	4
Maintenance	4
Storage and Transportation	4
Warranty	4
Liability	4
Safety Instructions	5
Spectral Power Distribution	5
Beam Angle	5
Technical Data	6

INSTRUCTIONS

1. MAGNETIC SWITCH

Attention: the light uses a magnetic switch, so your compass reading may be off when you hold it close (within 5cm or 2") to the black on/off switch.

2. CHARGE OF THE BATTERY

Only use the supplied Li-lon charger to charge the battery. For best results, the battery should be charged at room temperature. Avoid charging when batteries are still hot after use. Let them cool down before charging.



Important: If battery state of health falls below 75%, always use the included 16.8V to 16.6V Adapter cable when charging.

3. MAINTENANCE OF BATTERY

It is not recommended to discharge the battery after each dive. Complete discharge after every use may reduce life time of battery. We recommend the following service procedures:

- For storage remove battery from casing.
- Discharge and recharge the battery at least once every 6 months.
- Avoid deep discharge of the battery pack.
- Store battery with approximately a 30-60% partial charge in a dry and cool place.
- Charge fully before each dive.
- The storage of a fully discharged battery may cause permanent damage to the battery.

4. BATTERY PROTECTION CIRCUIT



The integrated protection circuit protects the battery from overload, overcharge and deep discharge.

5. CHARGE LEVEL INDICATOR

The green charge level indicator displays the available relative charge and the two digit display shows the remaining run time at the actual power setting. The display unit is 1 minute. While charging the 2 digit display shows the remaining charge time. The unit is 10 minutes. The display is turned off when the battery is fully charged.

6. USE IN AIR

The video light can also be used outside water but at low power level only. If the light gets too hot, it slowly and automatically reduces the power to avoid overheating.

7. HOW TO OPEN THE CASING

Remove excess water from the outside before opening. Point the light slightly upward while opening to avoid water from entering the housing.

Friction of the O-ring seal (and therefore force needed to open the cap) increases over storage time. After long and deep dives the friction might increase too. To avoid high friction, regularly grease the O-ring.

8. MAINTENANCE

After each use rinse well with fresh water.

Care should be taken to avoid scratching of the O-ring seals. Keep seals clean of sand, hair, cloth fibers or similar materials at all times. O-rings of the battery screw cap should be regularly inspected and cleaned. Occasionally apply small amounts of silicone grease for lubrication. If not treated, the O-ring will fail to provide proper sealing causing the light to malfunction.

- Do not use sharp tools to remove the O-ring.
- Never use a battery which appears damaged.
- In case of a damaged lamp, contact your nearest KELDAN® dealer.
- Do not remove front glass cover (high operating voltage).
- O-rings need to be replaced by KELDAN® or an authorized dealer every 5 years.

9. STORAGE AND TRANSPORTATION

Battery and casing must be stored apart in a cool and dry place. Maintain battery pack according to our recommendations. Separate battery pack from casing if traveling by air.

12. WARRANTY

The light carries a two-year warranty after purchase (proove of purchase date required). The warranty is limited to material defects which occur when correctly handling the product. The warranty does not cover the battery packs.

KELDAN® warranty coverage is void for defects as a result of improper use.

11. LIABILITY


KELDAN[®] declines all responsibility for damages arising from any improper use of the VIDEO 8X 18000lm CRI85 light or as incurred by a third person.

SAFETY INSTRUCTIONS

The VIDEO 8X 18000Im CRI85 light produces an extremely powerful and intense light.


- Never point directly at a person at close distance.
- Never stare directly into the light.

SPECTRAL POWER DISTRIBUTION



Spectral Power Distribution

BEAM ANGLE



VIDEO 8X 18000Im CRI85 Operating Instructions

RISK GROUP 2

CAUTION. Possibly hazardous optical radiaton emitted from this product. Do not stare

at operating lamp. May be harmful to the eye.

TECHNICAL DATA

Battery (Li-Ion)	14.4V / 99Wh
Charging time	3-4 hours
Diameter / Length	7 / 23,5 cm
Weight (in water)	0,88 (0,30) kg
Maximum depth	200 m
Color temperature	5600 K
Color rendering index	85 CRI (Ra)
Beam angle in water at 50% intensity	90°
Beam angle in water at 25% intensity	110°

POWER SETTINGS

Luminus Flux	Candlepower	Burn Time	Electrical Power
18'000 lumen	7700 candela	35 min	135 watts
10'000 lumen	4300 candela	80 min	63 watts
5900 lumen	2500 candela	140 min	36 watts
3400 lumen	1500 candela	240 min	20 watts
2000 lumen	860 candela	380 min	13 watts
1100 lumen	500 candela	570 min	9 watts
650 lumen	280 candela	950 min	6 watts
380 lumen	160 candela	1200 min	4 watts
220 lumen	100 candela	1400 min	3.5 watts



KELDAN GmbH Industriestrasse 37a 2555 Brügg Switzerland Tel: ++41 32 333 16 28

www.keldanlights.com contactus@keldanlights.com



KELDAN[®] is a registered trademark of KELDAN GmbH.

Subject to change without notice, February 2023.

